




ONE LANE WIDTH PATCH




ONE LANE WIDTH PATCH




ONE LANE PATCH  
(NO OPPOSING JOINT)




FULL ROADWAY WIDTH PATCH



FULL ROADWAY WIDTH PATCH




PARTIAL LANE WIDTH PATCH




DETAIL FOR 'RT' OR 'RD'  
JOINT BAR SPACING

TYPICAL HALF PLAN  
For interior lanes, place first bar  
12" from edge of lane (slab).



LONGITUDINAL SECTION THRU PATCH



PAVEMENT REMOVAL DETAILS



BAR SIZE TABLE			
Existing PCC Pavement Thickness	Less than 8"	8" to 10"	More than 10"
DOWEL SIZE	3/4"	1 1/4"	1 1/2"
TIE BAR SIZE	#6	#10	#11

See PV-101 for joint and bar placement details.  
Construct rectangular patches even when existing pavement joints are skewed.  
Min. length of patches on interstate project is 6 feet.

- Joint spacing 10 feet minimum, 17 feet maximum, 15 feet optimum.
- If there is no existing joint or crack in the adjacent pavement, place a 'CT' joint. If there is an existing joint or crack in the adjacent pavement, place a 'CD' joint at the same transverse location. Saw but do not seal 'CT' joints.
- New 'CD' joint must be a minimum 5 feet from the patch end.
- Do not saw or seal the joint. Place 1/2 inch preformed joint material between patch and concrete in adjacent lane.
- If one lane patch exceeds 50 feet, both lanes should be considered for patching.
- Possible Subbase Patch, see PR-140.
- If longitudinal subdrain (shoulder) is not to be placed or if it is not present on side of roadway to be patched, then place drain per PR-140.

Possible Contract Items:  
CD Joint Assembly  
CT Joint  
Patches by Count (Repair)  
Patches, Full-Depth Finish, by Area  
Patches, Full-Depth Finish, by Count  
Patches, Full Depth Finish, by Area (50 feet in length or greater)  
Patches, Full-Depth Repair

Possible Tabulation:  
102-6C

 IOWA   DOT		REVISION	
		4	10-21-25
STANDARD ROAD PLAN		PR-103	
		SHEET 1 of 1	
REVISIONS:      Removed 'KT-2' joint option.			
			
APPROVED BY DESIGN METHODS ENGINEER			
FULL DEPTH PCC PATCH WITH DOWELS			